



# SUPERSEAL Carpet & Laminate Subfloor

## No Plywood, No Nails, No Glue

### Installation Instructions



- Sweep up all loose debris.
- Ensure your floor is flat prior to installation.
- Fill any low spots with a leveling compound.
- Do not install under a load bearing wall

1. Let the membrane climatize to room temperature (approx 65° F - 20° C)
2. Unroll the Membrane and flip it over. This helps prevent the membrane from curling up at the edges. You can also back roll the ends.
3. Cut to fit leaving a ¼ inch space at walls, posts, stairs etc.
4. When joining 2 pieces, butt the edges together and tape with moisture barrier tape.



Unroll and tape seams

### Installing the Tack Strip & Carpet

Nail the tack strip through the membrane. Once fastened to the substrate, install your carpet pad and carpet as per the manufactures instructions.

When installing the tack strip, you may require additional concrete tack strip nails.



Install tack strip



Install carpet pad & carpet

### Installing Laminate / Engineered Wood

Install a layer of laminate foam underlayment on top of the membrane. Proceed with the installation of the laminate or engineered interlocking wood floor as per the manufactures instructions

\*Flooring with foam already attached, can be installed directly on membrane.



Install laminate foam and flooring