

PRODUCT BENEFITS

Install Anywhere

SUPERSEAL SHOWER N FLOOR can be installed wherever a waterproofing or anti-fracture membrane is needed.

Waterproofing Barrier

Surface & substrate moisture cannot penetrate the tough long lasting membrane. This helps stop cracking & tile delamination

User Friendly, Quick & Easy

SUPERSEAL SHOWER N FLOOR is 90% lighter than cement board or plywood making it very easy to transport. It's 10x faster to install & has minimal waste.

Reduced Labor = Big Savings

SUPERSEAL SHOWER N FLOOR requires no nails or screws reducing materials & installation time, providing savings up to 70%



Instructions & Requirements


Tools required: tape measure, marker, chalk line, scissors, utility knife, 1/4" or 3/16" notched trowel, mixing bucket, mixing device, level

- The substrate must be clean, durable, even, and load bearing for intended use.
- Use pre shaped inside and outside corners and Seam Cloth for long corners.
- Modified thinsets on wood. Unmodified on drywall or cement board. Fast-set thinset in cold conditions and on lino and existing tile surfaces. Scuff shiny surfaces with 100 grit scuff pad or sandpaper. A floor scuffer can be rented.
- Ensure shower bases and floor drains slope to the drain. Shower bases can be poured concrete.

Installation

1. Precut all pieces and mark the areas they cover.
2. Mix thinset so it barely holds the shape of the trowel and will stay on the wall. Install only as much thinset as you can handle within the drying time. It's easiest to stay within the areas of the shapes and sizes you have already precut and marked out on the substrate.
3. Apply thinset to corner substrate and install all corners. Press and trowel tightly into place. Remove excess thinset.
4. For pipes, cut a piece of the membrane at least 2" larger in each direction of the pipe. Cut an "X" in this piece slightly smaller than the pipe. Apply thinset to the wall area around the pipe and slide the piece over the pipe and trowel flat.
5. Spread the thinset evenly on the wall or floor of the pre marked area. Apply the membrane and ensure all joints overlap a minimum of 2". For horizontal joints overlap top to bottom.
6. Starting from the center out, use the flat side of the trowel on a 45° angle to embed the membrane into the thinset forcing air pockets and excess thinset out. Thinset should extend beyond the membranes edges.
7. Install tiles once the thinset firms up. For tiles, use thinset recommended by tile manufacturer.

Over Walls or Floors



NOTE: Modified thinsets require longer drying times



SUPERSEAL Shower N Floor

1 Install base and Corners



2 Apply thinset to main areas



3 Apply membrane, smooth out (ready for tiles)



This brochure is only a guide and is not intended to be an installation instruction. For detailed instructions refer to roll label or go to www.superseal.ca

Installation Tips

- Ensure the substrate is clean and flat
- Pre cut all pieces to size
- Use a 1/4" to 3/16" notched trowel on a 45° angle

Product Applications

SUPERSEAL SHOWER N FLOOR is an easy to use waterproofing membrane. It's made from 3 layers of cross laminated polyethylene with fleece fabric bonded to both sides. It conforms to:

TCNA C-627, ANSI A118.10-99



- 100% Waterproof - average showers can be ready for tiles in about an hour
- Can be installed over drywall
- Quick and easy to use
- 90% lighter than backer board
- Easy to carry & install

Part# Roll Sizes

TW82165	3'3" x 16'6" (54ft ²)	1m x 5m
TW82985	3'3" x 98'6" (323ft ²)	1m x 30m

Seam Cloth

TC82561	5" x 16'6" - 12.7cm x 5m
TC82589	5" x 98'6" - 12.7cm x 30m

Corners	Inside	Outside
2 per pack	TO82111	TO82200



SUPERSEAL SHOWER N FLOOR

WATERPROOFING & CRACK PREVENTION MEMBRANE



SUPERSEAL Construction Products Ltd.
www.superseal.ca

SUPERSEAL Waterproof Membrane™